



LED Rock/Dome Light Instructions

Congratulations on purchasing a Baja Designs rock/dome light. Installation can be performed two different ways.

1. Utilizing the included tube mount, install the shorter M4 hardware through the rock light and overmold secure the back with the provide M4 nuts. Once the rock light has been installed you can slide the provided zip tie through the zip tie channel followed by securing the rock light and tube mount to the desired location.
2. Drill and tap two M4 x 0.7 holes while utilizing the longer M4 bolts mount the rock/dome light unit to your vehicle.

The rock/dome light requires 12v power. The red wire is positive and the black wire is ground. The unit can become hot so be careful it is not mounted near anything that may melt or be damaged by the heat. If you have any questions regarding the installation please contact Baja Designs at 760-560-2252.



LED Rock/Dome Light Instructions

Congratulations on purchasing a Baja Designs rock/dome light. Installation can be performed two different ways.

1. Utilizing the included tube mount, install the shorter M4 hardware through the rock light and overmold secure the back with the provide M4 nuts. Once the rock light has been installed you can slide the provided zip tie through the zip tie channel followed by securing the rock light and tube mount to the desired location.
2. Drill and tap two M4 x 0.7 holes while utilizing the longer M4 bolts mount the rock/dome light unit to your vehicle.

The rock/dome light requires 12v power. The red wire is positive and the black wire is ground. The unit can become hot so be careful it is not mounted near anything that may melt or be damaged by the heat. If you have any questions regarding the installation please contact Baja Designs at 760-560-2252.