



baja designs[®]
THE SCIENTISTS OF LIGHTING

2014 - 2023 Street Glide DOT LP6 Headlight Kit Instructions

44-8114 & 44-8115



2950 Norman Strasse San Marcos, CA 92069

Phone 760-560-2252 X3 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
THE SCIENTISTS OF LIGHTING

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse, or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace it with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

*****For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com *****

Parts List:

LP6 Adapter Bracket
6/32x5/8" Machine Screw

Parts List:

To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.

Step 1: Remove the factory light trim ring, followed by the factory light and bracket. Save the screws that attached the "Outer" light ring to your fairing.

Step 2: Unplug your factory light and set it aside on a microfiber towel or surface that will prevent scratches.

Step 3: Using the 1/4x20 bolts supplied in the included hardware bag, attach the DOT LP6 light to the new bracket, leave the front adjustment bolts slightly loose for future angle adjustment.

Step 4: Connect the DOT LP6 Harness into the back of light, followed by the OEM harness, and set the entire light assembly inside your fairing. Do not fully tighten the adjustment hardware yet.

Step 5: Ensure the light is level. The ideal setting is 87.5 Degrees when the bike is level on the ground (not resting on its kickstand).

Step 6: Once the light is at the ideal angle, remove the DOT LP6 Assembly and tighten down the 4 bolts using a wrench. Then place the assembly back into the fairing.

Step 7: To reinstall the factory trim ring locate the spring on the inside top portion of the OEM light bezel trim ring. Insert the trim ring with the spring at about the 11 o'clock position. Rotate clockwise until the spring catches the hook circled in the image below. Next, insert the 6/32 Phillips pan head screw under the trim ring into the threaded hole. *Do not overtighten the screw, this can cause the trim ring to warp/crush.*****



Step 8: Tie up any loose cables and wires to ensure nothing is pinched or caught when reinstalling the OEM fairing.

*Tie all wires away from sharp, hot, and/or rotating components.

* Re-torque all the fasteners after 100 miles.

*Your install is now complete! Thank you for choosing Baja Designs.