



baja designs®
THE SCIENTISTS OF LIGHTING

2024-2026 Ford Ranger Raptor

Fog Pocket Kit

S1 (Clear or Baja Amber), Wide Cornering

44-8358, 44-8359



2950 Norman Strasse San Marcos, CA 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
THE SCIENTISTS OF LIGHTING

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse, or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace it with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

*****For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com *****

To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.

Remove the front wheels for ease of access. Retain all factory hardware for reinstallation.

Required Tool(s):

- T30 torx bit/driver
- T25 torx bit/driver
- 3mm Allen head bit
- 10mm wrench/socket-ratchet
- 7mm wrench/socket-ratchet
- -

Step 1: Start by removing the 2 T30 bolts and the 1 10mm bolts to remove the plastic air vent.



Step 2: Remove 2 size 7mm bolts and 3 Phillips screw clips to loosen the fender liner.



Step 3: Remove the factory fog light plug from the factory light.



Step 4: Remove 3 T25 bolts holding the factory fog light in place.



Step 5: LIGHT AND MOUNT ASSEMBLY

Position the light with the front mount bracket and align the 4 bolts of the light to the alignment slots on the mount.



Step 6: Using the bolts supplied with Baja Designs S1 lights, secure the 2 hex head bolts (size 3) on each side of the light with the rear mount bracket. Do not overtighten.



Step 7: Grab your light with the mount installed, (rear mount will be loose until secure to the truck) and place it in the mounting location. Place the mount and light into the original factory fog light position by twisting and turning to slot it in. Once in position secure the 2 mounts with T25 torx bolts. Do not overtighten as they are self-tapping screws.



Step 8: Secure the piggyback harness to the factory plug, then plug in your S1 light. Secure wiring to frame with zip ties.



Step 9: Repeat steps for the other side.

*Tie all wires away from sharp, hot, and/or rotating components.

* Re-torque all the fasteners after 100 miles.

*Your install is now complete! Thank you for choosing Baja Designs.