



***baja designs***®  
THE SCIENTISTS OF LIGHTING

**Jeep JK Roof Bar kit,  
XL Linkable, 50" OnX6+, 50" S8**



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 x3 • Fax 760-560-0383

info@bajadesigns.com • [www.bajadesigns.com](http://www.bajadesigns.com)



***baja designs***<sup>®</sup>  
THE SCIENTISTS OF LIGHTING

## LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

### **Exclusions:**

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

### **Indemnification:**

**Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies**

## Jeep JK Roof Light Bar Instructions

### Tools Required

- T40 Torx Driver
- 7/16" wrench
- 3/16" Allen wrench

### Directions:

1. With the T40 Torx driver, remove the five bolts on each side of the windshield (10 total). Driver side bolts circled on the right.
2. Place each bracket over the holes from step one, thread in, and hand tighten the bolts. Anti-seize recommended. Once all bolts are in, tighten.
3. With an assistant, place the lightbar in between the brackets and tighten the hardware. For OnX6+ and S8, only the 7/16" wrench will be needed. For the XL Linkable, 7/16" wrench and 3/16" Allen wrench will be needed.
4. Remove the two circled Torx bolts on the passenger side windshield wiper cowl panel with the T40 Torx driver.
5. Open the hood and route the light plug lead of the harness under the windshield wiper cowl and up the passenger side bracket as shown by the arrows. Tie up the harness using the zip tie slots on the bracket. Tighten wiper cowl bolts.
6. Under the hood, route the switch lead of the harness across the firewall from the passenger side over to the driver side. Take a quick picture of the switch wiring to reference later. Pierce a hole through the firewall passthrough grommet, located on the driver side of the brake booster bracket. Remove wires from switch and route switch terminals through firewall. Mount the switch and reconnect the switch terminals.
7. Connect harness to the battery terminals.  
**\*Do not use the nut closest to each post\***
8. Turn on light, aim, then tighten. Tie up wires away from all hot, rotating, and/or sharp components.

Re-torque fasteners after 100 miles.

Your installation is now complete, thank you for choosing Baja Designs!

