



baja designs.
The Scientists of Lighting



Security Hardware Kit Installation Instructions

(PN: 66-0303)

Baja Designs ♦ 185 Bosstick Blvd. ♦ San Marcos ♦ CA ♦ 92069

Phone 760.560.2252 ♦ Fax 760.560.0383

www.bajadesigns.com



For Part number 66-0303 (3/8" Tamperproof, Security Hardware Kit)

QTY	Description
3	Security Hardware, 3/8"-16 Sloped Nut

Please read this manual prior to installation.

- 1.) This Security kit will include three 3/8"-16 sloped nuts. For use on auxiliary lights with U-Bracket mount only two sloped nuts are needed. For use on Light Bar mounts all three sloped nuts will be needed.
- 2.) Thread one sloped nut onto the 3/8" mounting bolt with the flat edge facing towards the bracket.
- 3.) Thread a second sloped nut onto the bolt upside down and insert a wrench between the two nuts to fasten.



- 4.) Then back off the upper sloped nut, leaving the bottom sloped nut fastened.

