




baja designs[®]
The Scientists of Lighting

Can-Am, Maverick X3 S8 shock mount kit

44-7037, 44-7038, 70-7503



2950 Norman Strasse Rd • San Marcos • CA • 92069

Phone 760.560.2252 • Fax 760.560.0383 • info@bajadesigns.com

www.bajadesigns.com



baja designs[®]
The Scientists of Lighting

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a **LIFETIME WARRANTY** against manufacturer's defect on all of the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and be able to supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a particular purpose. We will however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Indemnification:

Buyer hereby acknowledges off roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and



baja designs
The Scientists of Lighting

hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

Exclusions:

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Instructions for Can-Am, Maverick X3 S8 Shock Mount Kit



1. First start by removing the front panel that covers radiator. Pull gently and it should pop off.
2. Once the front panel is taken off, remove two bolts shown in picture 1 above.
3. Then install the two brackets, with the washer provided between the bracket and the mounting surface (Photo 2 & 3). Make the brackets tight enough to be able to install the S8 between the two brackets and adjust them.
4. Install the S8 between the two brackets. Once the S8 is securely fastened in the brackets, adjust the brackets so the light sits straight and level. Once you are happy with the position of your light tighten the mounting bolts of the brackets.



baja designs
The Scientists of Lighting



5. Remove the light from the brackets, and carefully place the front panel back onto the Vehicle. Then reinstall the S8 back into the brackets. (Photo 5)

Wiring Guide

1. Use the provided harness and connect the light bar.
2. Determine a desired dash location for the rocker switch.
3. Connect the +12V (red wire) to the positive terminal on the Bus Bar under the hood (not the accessory power) and the -12V ground (black wire) to the negative terminal.

Use caution if using zip ties to not pinch the wires