



baja designs[®]
THE SCIENTISTS OF LIGHTING

Toyota, Tacoma 30" S8/OnX6 (05-15) Mounting kit Instructions



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 x3 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
THE SCIENTISTS OF LIGHTING

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:


Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies

Toyota, Tacoma 30 inch OnX6/S8 Mounting Instructions



Tools Required

- 7/16" socket wrench
- 10mm Socket Wrench
- 14mm Socket wrench
- Dremel, or Hack saw

On years (12-15) trimming is required in order to run a OnX6, although the S8 does not require it. In the lower grille, use the Dremel, or hack saw in the 16 circled locations to trim across the plastic in the center of the grill.



1. The 30" light bar brackets will mount off the outside frame bumper mounting nuts. The location is shown by the dashed circles.
2. With the 14mm socket wrench, remove the two arrowed outside bumper mounting nuts on the Driver side. Mount the Driver side bracket and tighten the nuts. Repeat for the other side.
3. Place and mount the light in between the brackets with the 7/16" socket wrench and hardware.
4. Unravel the harness and route the light plug lead of the harness down to the passenger side of the light from the engine compartment (see arrows in step 1).
5. Route the switch lead of the harness to the firewall passthrough grommet next to the brake booster. Snap a photo of the switch wiring. Remove the switch terminals from the switch, pierce a small hole in the passthrough grommet, route switch wires through, mount switch, and reattach switch terminals.
6. Attach positive ring terminal of the harness to the battery with the 10mm socket wrench. Then attach negative ring terminal. Tie the harness and relay away from all hot, sharp, and/or rotating components.



Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.