



baja designs[®]
THE SCIENTISTS OF LIGHTING

**22-on Polaris RZR Pro-R A-Pillar Kit
(44-8103, 44-8104, 44-8105, 44-8106)**



2950 Norman Strasse • San Marcos • CA • 92069

Phone 760-560-2252 X3 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
THE SCIENTISTS OF LIGHTING

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

Tools Required

*T-40 Torx	*7/16", 9/16", 18mm, 19mm sockets	*9/16", 18mm, 19mm wrench
*Tape	*Scissors or knife	*Torque wrench

To begin, make sure the vehicle is in park and on level ground.


1. Fold up the rubber boots located at the base of the driver side A-pillar (as seen in photo 1). Using an 18mm wrench and socket, remove the two cage bolts. Unfold the boot.

2. Cut out the driver side trimming template (found at the back of the instructions) and tape it to the A-pillar boot using the accent lines (outlined in white in photo 2) to align it. Mark the oval shaped hole on the boot with a marker and remove the template. Cut the boot until none of the marker is left and the bolts and spacers fit without interference.




3. Using the included flange head bolts, nuts, washers, and spacers, attach the driver side vehicle specific bracket to the A-pillar. With a torque wrench, tighten the hardware to 89 ft-lbs using 18mm and 19mm sockets.

4. Insert the 9/16" hex head bolt into the light mounting bracket before installing the light. With a 7/16" socket and the included hardware, attach the light to the light mounting bracket.



5. Mount the light onto A-pillar bracket with the 9/16" head bolt and 9/16" wrench and socket. **For XL lights, lift the base of the boot near the tweeter and route the power cord through the hole.**

6. Repeat steps 1 through 5 for the passenger side of the vehicle.





7. Open the dash center console and remove the console insert. Locate the pulse bar and remove one of the pulse bar caps. Plug in the included wiring harness to the pulse bar.

8. Locate the rocker switch on the wiring harness, take a photo of the wiring and unplug the spade connectors. From the passenger side footwell, reach up into the dash and locate the back of the desired rocker switch punchout and carefully press it out.



9. Run the switch wires through the dash to the desired switch location. Plug in the switch wires following the reference photo from step 8 and install the switch into the dash.

10. Run both harness light leads through the firewall passthrough (Boxed) located in the passenger side footwell. Route a lead to either A-pillar light ensuring to avoid any hot, moving, or sharp components. Plug the harnesses into the lights. **For LP4s, run the plugs underneath the A-Pillar boot to the lights.**



11. Test the lights and ensure all wires are secured away from any hazards. Any excess wire should be bundled into a service loop and secured in the dash.



*Tie all wires away from sharp, hot, and/or rotating components.

* Re-torque all the fasteners after 100 miles.

*Your install is now complete! Thank you for choosing Baja Designs.

6



5

4

3

2

1



6

5

4

3

2

1