



**Can-Am, (2024-On) Maverick R, Mini6 SourceLT**

**Center Console Kit**

**(87-0139)**



2950 Norman Strasse San Marcos, CA 92069

Phone 661-775-7799 • Fax 760-560-0383

tech@4x4s-pod.com • [www.4x4spod.com](http://www.4x4spod.com)



## Warranty & Returns Policy

### WARRANTY AND REPAIR POLICY

sPOD offers a non-transferable 5-year limited warranty on electronic parts and components from manufacturers defects from the date of purchase (Effective on products purchased after 4/1/23). sPOD will repair or replace items in question and return them to Buyer at no charge. If the identical product is no longer available, sPOD will replace with a similar product of equal value. sPOD will not be responsible for any indirect or consequential damages in connection with defective merchandise.

### Exclusions:

Products that have been subjected to abuse, misuse, accident, alteration, modification, improper installation, tampering, or any use other than the product's designed purpose will void the warranty. The sPOD warranty excludes the following: Installation errors, abuse, misuse or crash damage, reverse polarity of battery cables, changing the 2 amp fuse for any other rated fuse, cutting off our connectors, splicing into our wires/harnesses, attaching anything other than our battery cables to our positive and negative terminal studs on our BantamX/SourceLT boards, changing our supplied switches (switch body), removing the actuators without using our specific actuator removal tool. This warranty shall be automatically voided if the items sent for warranty replacement are modified in any way or were not used as intended or applicable. Additionally, this warranty excludes normal wear and tear. NOTE: Any or all aftermarket brake controllers, hi-amp solenoids or any hi-amp relay that is attached to the same positive battery post will cause irreversible damage to the sPOD system. This will void all warranties. This warranty shall be automatically voided if the items sent for warranty replacement are returned with water/liquid/chemical damage to any electrical component.

The buyer MUST provide a copy of the original invoice or have completed the online product registration. Shipping responsibilities and/or charges will be determined once a claim has been opened. sPOD systems will be repaired or replaced at manufacturer's discretion. This warranty does not cover miscellaneous expenses, including, but not limited to, outside labor costs incurred for the installation, removal, replacement, and repair or troubleshooting. **Please contact sPOD to assist with troubleshooting prior to uninstalling your entire system as the solution may not require that the system be removed.**

All claims must be made in writing by mail or e-mail directly to sPOD:

By Mail: sPOD 2950 Norman Strasse Road San Marcos, CA 92069

By E-mail: Tech@4x4s-pod.com



## **RETURN AND REFUND POLICY**

sPOD will accept returns within 30 days from receipt of merchandise under the following conditions: Merchandise needs to be returned unused, with all printed material and accessories enclosed. If not in its original condition or the product shows signs of installation, additional charges will be applied or may not be accepted. All returns must be accompanied with a return merchandise authorization (RMA) number (to be provided by sPOD at time of request) and a receipt of original purchase.

To obtain an RMA number, please email [Tech@4x4S-pod.com](mailto:Tech@4x4S-pod.com) with your full name, invoice number, and part number of the item(s) you need to return.

A 15% percent restocking fee will apply after 30 days. All shipping charges are at the buyer's expense. The original shipping fees are non-refundable. We strongly recommend you insure all packages before shipping. We are not responsible for lost or stolen merchandise while in transit. We assume liability once the returned system has reached our facilities. Once your return shipment has been received and approved, your return will be processed. Failure to comply with the process and terms stated above may result in a processing delay and/or a refusal of the returned package.


**The above warranties and policies are subject to change without prior notice.**

**\*\*For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com \*\***

**Required Tool(s):**

- 7/16" Socket
- Size 2 Phillips head screwdriver
- 10mm socket


**Parts List:**



**(SourceLT Unit) (QTY: 1)**




**(Mini6 Assembly) (QTY: 1)**



**(44-9412) (QTY: 1)**

Can-Am, Maverick R, sPOD, Mini6/HD  
Center Console Bracket




**(44-9413) (QTY: 1)**

Can-Am, Maverick R, sPOD, PCM Bracket



**(20-1287) (QTY: 4)**

Hardware, 1/4-20 X 7/8 Hex Head Bolt SS




**(20-1278) (QTY: 4)**

Hardware, 1/4"-20 Extruded U Nuts



**(20-1282) (QTY: 4)**  
Hardware, 1/4 Flat Washer SS



**(20-1612) (QTY: 12)**  
Hardware, Zip Tie 50lb 8"



**(91-0790) (QTY: 1)**  
3 piece 12" Battery Cables




**(91-0030) (QTY: 1)**  
5 Foot Universal ethernet control cable



To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.

**Step 1:** Remove the electrical accessory cover by pulling up the latch. The positive and negative battery terminal posts are shown in the photo.


Fuse box cover



**Step 2:** Next step is to mount the sPOD module on the PCM bracket (44-9413). Open the cover of the PCM module using the thumbscrew. Place the gasket between the PCM and bracket. Secure the PCM using the 4 flathead bolts and a Phillips head screwdriver. Run the battery cables through the bracket and PCM. Attach them to the PCM battery posts using a 7/16" wrench.



**Step 3:** Inside the fuse box cover, place the four (included) clip-on U-nuts around the four tabs (circled) by sliding them over the holes until you here a click.




**Step 4:** Use a 7/16" socket and 1/4"-20 hardware with washers to mount the PCM bracket on to the U-nuts. Close the PCM module cover.






**Step 5:** Connect the positive (Red) battery cable to the positive power. Then, connect the negative (black) terminal of the PCM to the negative post. (See step 1)



**Step 6:** Carefully pull out the switch panel. This will create an empty space.




**Step 7:** Run the 5 feet ethernet cable via this duct.



Switch Lead goes into opening and straight down






**Step 8:** In the driver's side footwell run the ethernet cable from the firewall underneath the panel as directed in the photo.



**Step 9:** Pull out the ethernet cable.



**Step 10:** Using a 7/16 socket, assemble your bracket mount and switch module as shown below. Tighten the nuts.



**Step 11:** Now, pull the ethernet cable through the empty space and plug it into the included Mini6. Tighten the nuts of the bracket.



**Step 12:** For installing the bracket, hook on the top edge first and then push it so the bottom edge gets inside the lip of the cavity. Make sure that bracket nicely snaps into the socket.



\*Tie all wires away from sharp, hot, and/or rotating components.

\* Re-torque all the fasteners after 100 miles.

\*Your install is now complete! Thank you for choosing Baja Designs.