



baja designs[®]
THE SCIENTISTS OF LIGHTING

DOT LP6 Ground Flicker Harness

(60-0088)



2950 Norman Strasse San Marcos, CA 92069 Phone 760-560-2252 X3 • Fax 760-560-0383 info@bajadesigns.com •

www.bajadesigns.com

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions: Installation errors, abuse, misuse, or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties. Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace it with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise. Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.


Indemnification: Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies. Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and

Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

****For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com ****

Required Tool(s)

- Pliers
- Razor blade/ scissors
- 7/16 wrench



To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.

Step 1: Disconnect the batteries

Disconnect the ground cable from all batteries.

Step 2: Unplug light

Unplug the Deutsch connector from the back of the DOT LP6.


Step 3: Prep the wires

Cut back the black PVC sheathing around the wiring harness. There should be roughly 2"-3" of wire exposed between the sheathing and the connector.



Step 4: Install the splice connector

Clamp the splice connector around the black wire going into the connector. Use pliers to ensure that the splice connector is fully attached.



Step 5: Install the ring terminal

Remove the rear bracket mounting bolt from the light using a 7/16” wrench. Put the ring terminal between the washer and the bracket and tighten the bolt.



Step 6: Repeat and reconnect the battery

Repeat steps 2-5 for the remaining DOT LP6s. Reconnect the negative battery cables and test to ensure the flicker is gone. If the flicker is still present, ensure the splice connector has pierced the sheathing on the black wire and is connecting to the bare copper.

Tie all wires away from sharp, hot, and/or rotating components.

Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.