



baja designs®
THE SCIENTISTS OF LIGHTING

Prinsu Roof Rack, XL Linkable 7 Light Kit



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 X3 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
THE SCIENTISTS OF LIGHTING

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies


Prinsu Roof Rack XL Linkable Kit Instructions

Tools Required


- 3/16" Allen Wrench
- 7/16" Socket
- Cutting wheel (if no cutout present)
- T30 Torx bit

* This kit is meant for Prinsu racks that have the 40" lightbar cutout on the front wedge. If cutout is not present, a centered rectangle can be cut from the top edge of the front wedge panel.
(1.75" x 42.5")


1. With the 3/16" Allen wrench, remove the center light housing bolts on one side. With the extra driver side bracket (shown in step 3) and longer hardware, assemble the center support as shown.




2. Mount the light to the remaining brackets using the 3/16" Allen wrench, 7/16" socket wrench, and the provided hardware. Tighten the mounting bolts.



3. Now, with the T30 Torx bit, remove one side of the rack on the first two crossbars. Carefully pull the side plate away enough to slide the six provided carriage bolts into the top exposed slot on the front crossbar. Replace the side bolts and tighten.
4. Arrange the six bolts within the slot approximately where the mounting bracket holes would line up on the lightbar.




5. With assistance, place the lightbar up to the mounting locations. Adjust carriage bolts to line up with bracket slots. Add washers and nuts.
6. With the 7/16" socket, center the light and tighten the hardware.



* The next steps were created using a Toyota Tacoma.

7. With the provided harness, route the light lead up to the lightbar power cord on the passenger side and plug it in.
8. Pull the slack out of the harness and route the battery leads across the firewall and to the battery.
9. Route the switch lead of the harness to a firewall passthrough grommet typically next to the brake booster. Take a photo of the wiring on the switch to reference later. Remove the switch terminals from the switch, pierce a small hole in the passthrough grommet, and route switch wires through. Drill a hole in a desired dash location where there is clearance behind. Then, mount the switch and reattach switch terminals.
10. Attach positive ring terminal of the harness to the battery with the 10mm socket wrench. Then attach negative ring terminal.



Re-torque all the fasteners after 100 miles.

Tie wires away from all hot, sharp, and/or rotating components.

Your install is now complete! Thank you for choosing Baja Designs.