



baja designs[®]
THE SCIENTISTS OF LIGHTING

Harness, 4-pin Deutsch On/Off 1-light (60-0058)



2950 Norman Strasse • San Marcos • CA • 92069

Phone 760-560-2252 x3 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



baja designs[®]
THE SCIENTISTS OF LIGHTING

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.


Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.

****For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com ****

Tools Required


* Wrench
* Drill

*Drill Bits (up to 3/4")
*Pliers



1. Disconnect the negative battery cable(s).



2. Using a wrench, connect the ring terminal with the red wire to the positive battery cable. Connect the black ring terminal to either a chassis ground or the negative battery cable. **DO NOT RECONNECT THE NEGATIVE BATTERY CABLE TO THE BATTERY.**



3. Route the light lead to its intended location and plug it into the light. If needed, this single lead can be paired with Baja Designs 4-pin Deutsch splitters and/or extensions to power up to 14A worth of lights.

4. Route the switch lead to a firewall boot and disconnect the two parts at the red connector. Select a location on the dash for a $\frac{3}{4}$ " switch and ensure there is clearance behind it. Drill a $\frac{3}{4}$ " hole and press the switch into place. Route the switch lead through the firewall and reconnect it to the harness. It may prove helpful to de-pin and re-pin the red connector. Take a reference photo of the wires and their location in the connector. If needed, BD PN: 64-1120 can be purchased to add additional length to this lead.

4.




5. If the backlight is to be activated via a 12V trigger, route the backlight lead to that source. It is recommended to use an IGN source rather than an accessory or DRL as it will provide more reliable signal. The harness comes with a splice connector, but fuse taps can be purchased from the Baja Designs website under BD PN: 63-9209.

If using the splice connector, place the 12V source wire into the two splice teeth (circled) and crimp the connector shut utilizing a pair of pliers. Ensure the connector is fully clamped shut and cannot easily pop open.

6. Secure the relay and any excess wire. Reconnect the negative battery cable to the battery. Test for proper functionality.

5.



*Tie all wires away from sharp, hot, and/or rotating components.

* Re-torque all the fasteners after 100 miles.

*Your install is now complete! Thank you for choosing Baja Designs.