



***baja designs***<sup>®</sup>  
*The Scientists of Lighting*

## **Anti-Flicker harness Instructions 64-0166**



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

[info@bajadesigns.com](mailto:info@bajadesigns.com) • [www.bajadesigns.com](http://www.bajadesigns.com)



***baja designs***<sup>®</sup>  
*The Scientists of Lighting*

## **LIMITED LIFETIME WARRANTY**

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

### **Exclusions:**

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

### **Indemnification:**

**Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.**




**baja designs**  
The Scientists of Lighting

### Anti-flicker Harness Instructions

#### Tools Required

- Circuit test light or multimeter
- 10mm or ½ socket  
(\*vehicle specific battery terminal tools\*)



#### **Harness diagram:**

**(1) Positive Battery Lead**

**(2) Negative Battery Lead**

**(3) Unpinned connector. This gets connected into the plug n play adapter supplied with the light kit**

**(4) Two leads to plug into lights. One side has an extension to reach to the furthest light from the battery**

1. Once your lights and mounting brackets are installed, make sure you can still access the OEM and Baja Designs light plugs.
2. Connect the positive**(1)** and negative**(2)** leads of the harness to the vehicles battery.
3. Route the two identical plugs **(4)** to each of the lights and the unpinned connector **(3)** to the OEM fog light wiring. The unpinned connector lead will go to the closest light to the battery.
4. Locate the plug n play adapter that came with the light and bracket kit.



**baja designs**  
The Scientists of Lighting

(Three common adapters are shown below)



5. Plug the adapter into the OEM plug. Some vehicle kits will come with the adapter unpinned and require that you check polarity of the plug leads. Using a multimeter or circuit tester, determine which wire is the ground (-) and which is positive (+12V-14V). The positive wire will correspond to the Weather pak (Baja Designs plug) terminal location B. Attach the weather pak on the end of the harness so it connects to positive voltage.



6. Plug in the other two leads to the two lights and secure the harness out of the way. You are now ready to use your fog lamps that will be activated by the factory switch!

Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.